

## Heat Defiant Fibre - HD

### Wigs, Hair Pieces, Hair Extensions

#### Cleanse & Condition

- Before washing your heat defiant fibre wig, hair piece or extension, gently remove any tangles with a wide tooth comb or afro comb **ONLY**
- Hold wig, hair piece or extension under cool running water.
- Gently lather the hair with a capful of **shampoo (paraben and sulfate free)** while making sure that the hair is travelling in the same direction. **DO NOT** rub hair as this may cause tangling
- Rinse thoroughly in cool water until the water runs clear
- For shorter styles:
  - Wrap wig, hair piece or extension in a towel and gently pat dry
  - Gently detangle hair using a wide tooth comb or afro comb
  - Use a **leave-in conditioning spray** (3-5 pumps) keeping away from base of wig, hair piece or extension
- For longer styles:
  - Use a **cream conditioner**, keeping away from base of wig, hair piece or extension, massage through ends and rinse out
  - Gently detangle hair using a wide tooth comb or afro comb

#### Curl

- Heat your curling tong to 180° C
- Using a wide tooth comb or afro comb, gently comb hair free of tangles
- For wigs start at the nape, take ½ inch-1.5 inch sections of hair (Smaller sections=tighter curls, larger sections=looser curls)
- For hair pieces or extensions start from underneath, take ½ inch-1.5 inch sections of hair (Smaller sections=tighter curls, larger sections=looser curls)
- Spray **Jon Renau Heat Treat Thermal Spray** on the section to protect the fibre (1-2 pumps per section)
- Gather hair into curling tong, smooth through to the ends. Roll tong up towards base of wig, hair piece or extension, staying 1-2 inches away
- Hold for 10-15 seconds, then turn the tip of tong toward the ground and release curl into palm of hand
- Holding curl in one hand, gather up towards base and secure curl with a small metal clip (like a pin curl)
- Allow curl to cool completely (about 5 minutes); remove clip and let curl hang naturally
- Hair can be combed with a wide tooth comb or afro comb or fingers for best results to blend curls

#### Dry & Style

- Air drying your wig will give the best results. You can gently blow dry (low-medium heat) using **ONLY** a wide tooth comb or afro comb
- Apply **Jon Renau HD Smooth Detangling Spray**, (3-5 pumps) focusing on the bottom half of wig, hair piece or extension. Gently comb through again with your wide tooth comb or afro comb
- We recommend that **ONLY** a wide tooth comb or afro comb is used on your heat defiant fibre wig, hair piece or extension. Other tools will cause frizzing/tangling
- Heat defiant fibre can withstand heat tools up to 180° C
- It is recommended to use professional grade heat styling tools with digital temperature settings to control heat

#### Straightening Iron

- Heat your straightening iron to 180° C
- For wigs start at the nape, take ½ inch-1.5 inch sections of hair
- For hair pieces or extensions start from underneath, take ½ inch-1.5 inch sections of hair
- Spray **Jon Renau Heat Treat Thermal Spray** on the section to protect the fibre (1-2 pumps per section)
- Staying at least 1-2 inches away from base, slowly smooth straightening iron down through ends
- Keep hair smooth by following behind the straightening iron with a wide tooth comb or afro comb
- Allow hair to hang naturally and cool completely

#### Tips

- We recommend using **Jon Renau HD Smooth Detangling Spray** with a wide tooth comb or afro comb daily to detangle your heat defiant fibre wig, hair piece or extension. This is especially important with the mid-length to long length heat defiant fibre wigs, hair pieces or extensions
- We offer **Jon Renau HD Smooth Detangling Spray** in a convenient 2oz. size for travel
- Allow your heat defiant fibre wig, hair piece or extension to air dry naturally instead of blow drying to help maintain the integrity of the fibre
- Help protect the fibre against heat damage by using **Jon Renau Heat Treat Thermal Spray** when using heat styling tools